

Thank you for your purchase of the **Iconasys Silver Series 360 Acrylic Riser Kit**. This is designed for use with an Iconasys Silver Series Turntable and will allow users to eliminate shadows when shooting 360 product views.

Included with your purchase:

- L Shaped Riser Legs (4)
- Clear Acrylic Disc (1)
- Screws (12)



***IMPORTANT \*\* The Acrylic Platform is fit snug into the bottom of the box. Please check to ensure all parts are included before discarding the packaging.***

**Set up instructions:**

1. Remove brown protective film from the Riser Legs and Riser Disc.
2. Screw in each of the L Shape Legs into the corresponding holes in the master turntable surface (3 screws per leg)
3. Place clear acrylic disc on top of riser legs.

