


Thank you for your purchase of the Iconasys 360 Acrylic Riser Kit. This is designed for use with an Iconasys turntable and will allow users to eliminate shadows when shooting 360 product views.

Included with your purchase:


- Aluminum Cross Bar (1)
- Screws (8)
- Nuts (8)
- Acrylic Risers (4)
- *Acrylic Platform (1)
- Adhesive Rubber Feet (4)



*** The Acrylic Platform is fit snug into the bottom of the box. Please check to ensure all parts are included before discarding the packaging.**

Set up instructions:

1. Remove protective film
2. Connect acrylic risers to Crossbar using screws and nuts. Note, small and medium acrylic risers will include 2 size risers when purchased with specific lighting kits. User can choose to use either size risers based on unique requirements.



3. Place rubber feet on base of crossbar (suggested). This will prevent the riser from slipping in between turntable start/stop.



4. Place acrylic top on acrylic risers